

SWITCHES

DRUM & ON/OFF STATIONS



PUSH BUTTON STATIONS

PBS - 603
FOR. - REV.
PBS - 602
UP - DOWN
PBS - 601
OPEN - CLOSE
1B - 100G
START
1B - 300R
STOP
SS - 600
START - STOP



DRUM CONTROLS

RS - 1

FOR. - OFF - REV.

RS - 1M

MOM. FOR. - OFF - MOM. REV.

.25 - 2 h.p.



DRUM CONTROLS

RS - 2 1 - 2 H.P.

FOR. - OFF - REV.

RS - 5 2 - 7 1/2 H.P.

FOR. - OFF - REV.

EURTON ELECTRIC CO., INC.
 9920 PAINTER AVE., P.O. BOX 2113
 SANTA FE SPRINGS CA 90670

800-423-4789
 fax 562-946-0014
 www.eurtonelectric.com